



Cord Lock Operated

Pleated, Roman & Cellular Shades

Installation Instructions

We recommend that all Jackson window coverings be professionally installed by a trained installer.

Step 1 Mount Your Brackets

Your Jackson Cord Lock Operated Pleated and Cellular Shades come complete with Universal mounting brackets for inside, outside, or ceiling mount.

Brackets require a 1 1/4" x 1 1/4" flat surface on wall or window frame. Mount brackets 3" in from each edge of the headrail with the screws provided. Additional brackets are required for blinds wider than 48". Make sure that the brackets are level. It is best to mount the brackets into a frame or stud.



Step 2 Install Headrail


Push shade into brackets, making sure front tip of bracket goes under lip of shade. The bracket will "click" when the shade is properly secured. If no "click", remove shade and re-level brackets.



Step 3 Raising & Lowering the Shade

To raise or lower the shade, pull the cord across the face of the blind. This action releases the cord lock and allows the blind to move.

To lock the blind in place, pull the cord towards the outside edge of the blind. This will engage the cord lock and hold the blind in place.



Unlock

Lock

Removing a Headrail

Push a screw driver in between the brackets and the rail. Making sure that you have control of the shade when it releases from the brackets. Twist the screwdriver to release the shade from the brackets, and rotate the blind out.



Cleaning Instructions

Jackson **Pleated Shades** and **Roman Shades** should require minimal care. It is important to dust shades regularly to prevent buildup. Use a soft, clean cloth or a vacuum cleaner with a brush attachment. Pleated Shade fabrics are delicate, therefore special care should be taken when cleaning.

Cellular Shade are easy to keep looking fresh and new for years. Regular dusting with a feather duster is recommended. When necessary, fabric can be lightly vacuumed with a brush attachment.

If Cellular shades become soiled with topical dirt (i.e. dirt that is resting on the surface of the fabric), we recommend that the shade be spot cleaned using a soft rag or sponge, a mild detergent and warm water. Extra care should be used when cleaning blackout fabric as the fabric could be permanently creased.

When it is necessary to clean the entire shade, the shade should be removed from the window and immersed in a tub filled with warm water and a mild detergent. (Do not attempt this if your shade features a motorized device, other specialty features or is made of Blackout fabric.) Gently wash with a soft rag or sponge. Rinse the shade with clean water, then close the shade and tilt to allow excess water to drain. Re-install the shade, lower it and allow it to dry.

Due to the differences in ultrasonic cleaning operators, we cannot recommend this method of cleaning. **Using Ultrasonic cleaning or any other method other than stated above will void the warranty.**



WARNING MISE EN GARDE
1-866-662-0666

<p>Young children can STRANGLE in cord and bead chain loops. They can also wrap cords around their necks and STRANGLE.</p> <p>-- Always keep cords and bead chains out of children's reach.</p> <p>--Move cribs, playpens, and other furniture away from cords and bead chains. Children can climb furniture to get to cords.</p> <p>--Do not tie cords together. Make sure cords do not twist together and create a loop.</p>	<p>Un jeune enfant peut s'ÉTRANGLER avec la boucle d'un cordon ou d'une chaînette. Il peut aussi enrouler le cordon autour de son cou et s'ÉTRANGLER.</p> <p>--Gardez toujours les cordons et les chaînettes hors de portée des enfants.</p> <p>--Éloignez les lits et parcs de bébé, ainsi que toute autre pièce de mobilier, des cordons et des chaînettes. Un enfant peut grimper sur un meuble pour atteindre les cordons.</p> <p>Ne nouez pas deux cordons. Faites en sorte que deux cordons ne puissent s'entremêler et former une boucle.</p>
--	--

For more information on blind cord safety, contact Health Canada toll free at 1-866-662-0666, or visit their website at:

www.healthcanada.gc.ca/blindcords

www.santecanada.gc.ca/cordons-stores






Clutch Operated

Pleated, Roman & Cellular Shades


Installation Instructions

We recommend that all Jackson window coverings be professionally installed by a trained installer.



Inside Mount

make sure that the tab is at the bottom.



Outside Mount

Step 1 Install the Brackets Outside & Wall Mounts

Your Jackson Clutch Operated Pleated and Cellular Shades come complete with Universal mounting brackets for inside, outside, or ceiling mount. It is important that the brackets are installed level.

Brackets require a 1 1/4" x 1 1/4" flat surface on wall or window frame. Mount brackets 3" in from each edge of the headrail with the screws provided. Additional brackets are required for blinds wider than 48". Make sure that the brackets are securely installed into the frame or a stud.

Inside & Ceiling Mounts

Brackets require at least a 1 3/4" recess for mounting. Front of headrail should normally be flush with the wall.

Projection Brackets (optional)



Projection brackets are not normally included unless specified on the original order. They can be used to extend the shade out to clear obstructions. Attach the snap clip to the projection brackets before installing the shade.

Important Note:

Pleated Shades have less fullness at the top than at the bottom. This does not affect the functioning of the shade. Occasional raising of the shade will assist in maintaining crisp pleats.

Step 2 Install Headrail

Position the top front lip of the headrail ("A") into the bracket, then push the rail up until it snaps into place. It is very important to install the front part first, then snap in the back tab, shown as item "B".



Step 3 Installing Cord Safety Device

This is a two piece device which restricts operation of the blind until it is fully installed. Measure the correct position to mount the bracket by allowing the safety device to hang down. Push the button and pull the cord to lower the blind. The device must be mounted in front of the blind so that the blind does not hit the safety device. Note that the bracket can be installed on the bottom, on the side, or rotated 90° and installed on the wall. Mount the bracket to the wall or window, then push the button and snap the arms of the safety device into the plus sign on the bracket. This will activate the pulley and allow the device to function.




Safety Device Bracket

It is highly recommended to use drywall plugs if you are not able to anchor to wall studs or window frame.




Side Mount



Bottom Mount



Wall Mount



Raising & Lowering the Shade

To raise or lower the shade, pull the cord loop. It is important to only operate the shade after it has been properly installed. Pulling on the cord loop when the shade is not hanging from the brackets, or manually raising the bottom bar may cause the lift cords to become tangled in the gears.



WARNING



MIS EN GARDE

1-866-662-0666

Young children can STRANGLE in cord and bead chain loops. They can also wrap cords around their necks and STRANGLE.

-- Always keep cords and bead chains out of children's reach.

--Move cribs, playpens, and other furniture away from cords and bead chains. Children can climb furniture to get to cords.

--Attach tension device to wall or floor. This can prevent children from pulling cords and bead chains around their necks.

Un jeune enfant peut s'ÉTRANGLER avec la boucle d'un cordon ou d'une chaînette. Il peut aussi enrouler le cordon autour de son cou et s'ÉTRANGLER.

--Gardez toujours les cordons et les chaînettes hors de portée des enfants.

--Éloignez les lits et parcs de bébé, ainsi que toute autre pièce de mobilier, des cordons et des chaînettes. Un enfant peut grimper sur un meuble pour atteindre les cordons.

--Fixez au mur ou sur le plancher un dispositif gardant chaînettes ou le cordon bien tendu. On peut ainsi empêcher l'enfant de saisir le cordon ou la chaînette et de s'enrouler autour du cou.

For more information on blind cord safety issues, contact Health Canada toll free at 1-866-662-0666, or visit their website at:

www.healthcanada.gc.ca/blindcords

www.santecanada.gc.ca/cordons-stores

Cleaning Instructions

Jackson **Pleated Shades** and **Roman Shades** should require minimal care. It is important to dust shades regularly to prevent buildup. Use a soft, clean cloth or a vacuum cleaner with a brush attachment. Pleated Shade fabrics are delicate, therefore special care should be taken when cleaning.

Cellular Shade are easy to keep looking fresh and new for years. Regular dusting with a feather duster is recommended. When necessary, fabric can be lightly vacuumed with a brush attachment.

If Cellular shades become soiled with topical dirt (i.e. dirt that is resting on the surface of the fabric), we recommend that the shade be spot cleaned using a soft rag or sponge, a mild detergent and warm water. Extra care should be used when cleaning blackout fabric as the fabric could be permanently creased.

When it is necessary to clean the entire shade, the shade should be removed from the window and immersed in a tub filled with warm water and a mild detergent. (Do not attempt this if your shade features a motorized device, other specialty features or is made of Blackout fabric.) Gently wash with a soft rag or sponge. Rinse the shade with clean water, then close the shade and tilt to allow excess water to drain. Re-install the shade, lower it and allow it to dry.

Due to the differences in ultrasonic cleaning operators, we cannot recommend this method of cleaning. **Using Ultrasonic cleaning or any other method other than stated above will void the warranty.**